

Magic Sheet
MUS Concert Hall
 2017

Front - Sensor							
Group 1							
14	13	12	11	10	9	8	
	7					6	
	5	4	3	2	1		

Front - Sine Wave							
Group 11							
	119	118	117	116	115		
114	113	112	111	110	109	108	
	107					106	
	105	104	103	102	101		

Top - Sensor						
Group 21						
	51	50	49	48	47	
46	45	44	43	42	41	40
39	38	37	36	35	34	33
32	31	30	29	28	27	26
	25	24	23	22	21	

Top - Sine Wave		
Group 31		
135	134	133
132	131	130
129	128	127
126	125	124
123	122	121

Specials	
<i>Zoom</i>	
84	82
83	81

High Side	
Group 41	
70	65
69	64
68	63
67	62
66	61

Sea Wash	
Group 51	
76	73
75	72
74	71

Movers	
<i>Varilite</i>	
98	97
96	95
94	93
92	91

Power		
Sea. H.S.	Sea. Wash	Movers
201	202	203

House				
House	Chairs	LEDs	Stairs	Booth
300	301	302	303	304

Dimmer Reference				
<i>Sensor: 1-96</i>	<i>SineWave: 197-134</i>	<i>House: 135-144</i>	<i>Switchable: 145-175</i>	<i>Architectural: 177-203</i>

